aiwa
Japan est1951

AT-X80ANC
True Wireless Earphones

※ Warning: Rechargeable batteries must be disposed properly. Please contact your local disposal/ recycling center for proper disposal. Do not expose the batteries to fire.

Designed in Japan
アイワ株式会社

Active Noise Cancellation (ANC)

ANC effectively blocks out surrounding noise by utilizing noise cancellation speakers to send a signal equal to the external ambient noise.

Charging the earbuds

Insert earbuds into a charged charging case.

Charging case indicator lights

Indicator light lights up when charging.
Indicator light turns off when fully charged.
Red LED flashes indicates low battery.
80% -100% battery lights up (Green) .
40% - 79 % battery lights up (Orange).
15% - 39% battery lights up (Red).

Swapping ear tips

Pull firmly to remove. Push down firmly until it clicks to attach.

Choose the most comfortable fit for your ears.

Bluetooth pairing

① Turn on Bluetooth
Turn on Bluetooth in the settings interface

② Connect AT-X80ANC
a) Open case, the AT-X80ANC enters the pairing mode
b) Find AT-X80ANC in Bluetooth
c) Click AT-X80ANC to connect

Earbuds control

Using both sides (L & R)

▶⏸	Ⓛ	Touch twice
⏩	Ⓡ	Touch thrice
⏪	Ⓛ	Touch thrice
🎤	Ⓛ	Long press 3 seconds
📞	Ⓛ	Touch twice
📞	Ⓛ	Touch twice
📞	Ⓛ Ⓡ	Long press 3 seconds

Earbuds control

One side (L/R) usage

▶⏸	Touch twice
⏩	Touch thrice
🎤	Long press 3 seconds
📞	Touch twice
📞	Touch twice
📞	Long press 3 seconds

Active Noise Cancellation Control

aiwa
Japan est1951

Aiwa Electronics Int'l Co., Ltd.
Explore more at www.int-aiwa.com

● Touch twice
Switch between "ANC on",
"ANC off" and "Transparancy mode"

Active noise Cancellation can only be controlled when using two AT–X80ANC at the same time

---

Specifications

BT Version: _____ V5.0
Transmission Distance:_____10M
Frequency Response:_____20–20KHz
MIC Sensitivity: _____99±3dB
Battery Capacity:____ (earphone)50mAh
_____(Charging box)500mAh
Rated Power: _____ 3mW
Driver Unit:_____φ10MM
Play Time:_____·About5H
Charging Time:_____·About1.5H
Supported Function: _____Active noise
____.reduction,Siri,Hall switch, up and
_____down switch, Music pause/play,
_____ answer/reject/hang up
Product Weight:_____5g

Product Accessories

1. Earphone 2. Charging Storage Case
3. Silica Gel Ear Cap 4. User Manual

Troubleshooting

I can't find "AT-X80ANC" on my Bluetooth's device's list.
Make sure "AT-X80ANC" and your device are within Bluetooth working distance (10m).
Remove the earphones from the charging case, enter pairing mode manually.
Re-attempt to pair again.

My earbuds can only answer calls/only listen to songs.
Re-start the earbuds.(Power down then power up)
Turn off mobile device's Bluetooth and turn it back on.
Delete all pairing data within mobile device.
Re-attempt to pair again.

There is no sound coming from my earbuds.
Please check volume level on both earbuds and connected mobile device.
Make sure "AT-X80ANC" and your device are within Bluetooth working distance (10m).
Re-attempt to pair again.

Unstable connection
Make sure "AT-X80ANC" and your device are within Bluetooth working distance (10m).

Maintenance
Please read the following suggestions to help you comply with the warranty and extend the life of the product.
• Keep the product dry and do not place it in a damp place, so asnot to affect the internal circuit of the product. It is necessary to avoid using this product during intense exercise or sweating to prevent sweat from penetrating into the product and damaging the product.
• Do not place the product in a place exposed to the sun or high temperatures. High temperatures can shorten the life of electronic components, damage batteries, and deform some plastic parts.
• Do not place the product in a cold place to avoid damaging the internal circuit board.
• Do not attempt to disassemble the product. If you are not a professional, you may damage the product.
• Do not drop, strongly vibrate, or hit the product with hardware to avoid damaging internal circuits.
• Do not use harsh chemicals or detergents to clean the headphones.
• Do not use sharp objects on the surface of the product to avoid damage to the outer casing and affect the appearance.

• If the product does not work properly, please send ittoyourqualified ser/ice facility and the staff will be happy to help you solve the problem.

Warranty
This product is covered under warranty for a period of one year from the date of sale limited to normal use and maintenance of the machine parts, materials and functions.Problems and failures verified upon further identificationwill be provided free repair and replacement parts.

THIS WARRANTY DOES NOT APPLY:
(a) to a product that is out of warranty;
(b) to damage caused by operating the product outside the permitted or intended uses described .
(c) to a product that has been disassembled, repaired or refitted by any third-parties
(d) if warranty card and proof of purchase cannot be presented;
(e) to damage caused by earthquake, fire or other external causes, natural disasters, etc.

Note: The warranty does not include product transport costs and does not provide on-site maintenance services

⚠ **AIWA reserves all rights to clarify this warranty interpretation**

Warranty Feedback Form(Tick off)

A. No sound
B. Sound quality deteriorates
C. Button mal-function
D. Unable to pair other device
E. Can not recharge
F. others

Buying time
_____

Dealers of sale
_____

Time of problems
_____

User's contact info
_____