



アイワ株式会社



-1-

設備概述 1. 觸摸區域 2. 麥克風 3. 充電接口 4. 充電盒指示燈



在使用AT-X80F耳機前請確保充飽電

請在使用AT-X80F之前將設備充滿電。 請使用合格的Type-C充電線將耳機充電。 外接充電線充電時,充電盒指示燈每秒燈閃爍一次 充電盒低電量警示燈每0.3秒燈閃爍一次 充電盒充滿電後,充電盒指示燈長亮 耳機開機:耳機指示燈亮1秒後熄滅 耳機配對中:耳機指示燈每0.2秒燈閃爍一次 耳機和設備連接中:耳機指示燈每秒燈閃爍一次 耳機和設備連接成功:耳機指示燈熄滅 耳機關機:耳機指示燈每秒燈閃爍一次,關機完成後燈滅 耳機入盒:耳機及充電盒指示燈亮5秒後熄滅 耳機恢復出廠設置:耳機指示燈每秒燈閃爍一次

-3-



| 自動開機,配對和自動關機




手動開/關機

A: 從充電盒拿出兩個耳機實現自動開機並且左右耳自動配對 長按左右耳機5秒實現手動關機並聽到語音提示關機。

> 耳機在關機狀態下,點擊左右耳機觸摸區域1-2次實現手 動開基,並能聽到語音提示開機。

手動配對

在手動開機後,雙擊耳機喚醒(不推薦手動配對)。



恢復出廠設置

確保耳機與智能手機或其他藍牙設備已經斷開連接



將兩隻耳機放入充電盒5秒,指示燈滅後取出耳機,連續 快速敲擊左耳機或右耳機觸摸區域5次,此時耳機的指示 燈會閃爍直至配對模式。成功恢復設置後,耳機會有"咚咚 咚"的提示音。



執行恢復出廠設置後,將耳機放入充電盒。再次取出時實 現自動開機和配對。 *請在手機端忽略(刪除)以配對的"AT-X80F"設備名稱,重

新搜索並配對使用。



語音提示

- 3. 您的設備已連接
- 4. 您的設備已斷開連接
- 5. 電量不足
- 7. 最小和最大 音量警報
- 8. 拒絕或結束通話警報 *適用某些Android手機,不支持IOS手機。

-7-

9. 重置成功提示

觸控指令



aıwa

Aiwa Electronics Int'l Co., Ltd. Explore more at www.int-aiwa.com

Japan est1951



Siri



在L或R耳塞上 點擊R耳塞2秒 點擊L耳塞2秒 輕按3次以輸入 Siri或Google助手













左或右耳塞

-8-



Designed in Japan

アイワ株式会社

Unboxing AT-X80F Earphone Charging Case Type-C Charging Cable Silicone Ear-tips

Contact your local authorized distributor/ customer service.

-1-

Device Overview 1. Touch sensor 2. Microphone 3. Charging interface 4. Charging case light indicator

Please charge your AT-X80F fully before usage.

-2 -

Charging Please charge your AT-X80F fully before usage. Indicator Status Charging by Type-C : Front indicator light flashes slowly (1 time/s) : Front indicator light flashes rapidly Battery Low : Solid front indicator light (Non-flashing) Fully Charged Power ON : Earbuds indicator lights should turn off after 1 second upon power on L & R Pairing : Earbuds indicator lights blinking Bluetooth Connecting: Earbuds indicator lights flashes rapidly Bluetooth Connected: Earbuds indicator lights flashes slowly (1 time/s)

Power OFF

: Earbuds indicator lights off


(1 time/s)

-3 -

Power on/off & Pairing A: Connecting both earbuds to each other. Remove both buds from the charging case. *Both buds flashing alternately (Red & Blue) indicates automatic pairing in *R side bud only flashes alternately (Red & Blue) indicates L & R side pairing B: Connecting the earbuds to your device. Select "Hi-Future FutureBuds Plus" from your device. *Voice prompt indicates successful connection* Earbuds into Case : Earbuds indicator lights off after 5 seconds : Earbuds indicator lights flashes slowly C: Powering Off earbuds Earbuds will shut down automatically within 60s after being placed back into the case. Earbuds will shut down automatically in 5 minutes upon disconnection with device.

-4-

Manual ON/OFF (To each other) same time.



Voice Prompt

- 1. Power ON 2. Pairing
- 3. Your device is connected
- 4. Your devices is disconnected
- 5. Battery Low
- 6. Power OFF 7. Min. & Max. Volume Alarm
- 8. Reject or End Call Alarm
- *Available for some Android phones, not support IOS phones.
- 9. Reset Succeed Alarm

MFB Instructions



aıwa

Aiwa Electronics Int'l Co., Ltd. Explore more at www.int-aiwa.com

Tap 3 times on the Tap R Earbuds for Tap L Earbuds for Short Tap

2 seconds

Double Tap L Earbuds

L or R earbud

to Enter Siri or

Google Assistance



Long Tap L or R Short Tap the

R Earbuds earbuds for 2 seconds L or R earbuds

2 seconds L or R Earbuds

-8-

-7-