

EB-X850BANC

Developed in Japan

Aiwa Electronics Int'l Co., Ltd.

Headphones

Warnings

- User's Manual Using earphones/headphones at moderate to high volumes for extended periods of - Carrying Case time will result in permanent hearing damage. We recommend that you always keep media playback volume level from low to moderate. Please do not use earphones while performing activities that require hearing surrounding noises/ sounds. (Driving, Cycling, jogging etc.)

- Please do not place device near any form of heat sources. 2. Please use the accessories specified by the manufacturer.
- 3. Please refer all servicing/repairs to a qualified personnel should there by any form VOLUME+/NEXT SONG of damage to the device. VOLUME-/PREVIOUS SONG
- 4. Keep this user manual for future referencing/ troubleshooting.
- Please heed ALL safety cautions.

Safety Cautions

3. Do NOT expose device to excessive heat (Direct sunlight etc.).

Important Safety Instructions

- 1. Always keep device AWAY from fire and heat sources.
- 2. Do NOT attempt to disassemble or alter the device.
- 4. Do NOT immerse device into any form of liquids.

The above are estimated values tested in a practical environment and may vary upon individual

Charging: DC 5V/1000mA Charger

Standby Time: Up to 300 Hours

Charging Time: 1.5 Hours

Playback/ Call Time: Up to 26 Hours (BT,ANC ON)

Product Specifications Model Number: FB-X850BANC BT Version: V5.0 Active Noise Cancellation: 20-25dB (between 100-150 Hz) Driver unit: 40mm Frequency Response: 20~20kHz MFB (0 Impedance: 32Ω + 15% Microphone Sensitivity: -42 dB Headphone Sensitivity: 98dB ± 3dB Supported Profiles: HSP/HFP/A2DP/AVRCP/AAC/SBC Transmission Distance (Estimated): 10 Meters (No Obstacles) Battery: 3.7V/650mAh (Li-on)

Product Overview

TYPE-C CHARGING PORT -

Unboxing

- 3.5mm Audio Cable - Type-C Charging Cable

- EB-X850BANC Headphones

Please refrain from using any damaged components. Contact your local authorized AIWA distributor/customer service should you need any assistance.

Product Usage Guide

► Play/Pause music: Click once (1).

Next Song: Press and hold.

Previous Song: Press and hold.

AUDIO PLAYBACK VIA AUX 3.5mm PORT :

from the in-built batteries of the headphones.

"+" BUTTON:

"-" BUTTON:

▶ Voice Assistant: Double click to activate.

ANC (ACTIVE NOISE CANCELLATION) BUTTON:

MFB (MULTI-FUNCTIONAL BUTTON):

Connect the 3.5mm audio cable to your audio source and headphones. I

automatically switches headphones to "Passive mode" where power is not drawn

- ▶ Power ON/OFF: Press and hold for three (3) seconds. ▶ Answer/End Calls: Click once (1).
- ▶ Reject Calls: Press and hold for two (2) seconds.

Turn ON/OFF ANC: Press and hold for one (1) second.

Increase Volume: Click once to adjust volume level. within connection range.

Connecting the Product

EB-X850BANC can connect to up to 2 mobile devices at the same time. Decrease Volume: Click once to adjust volume level.

To pair with two (2) devices:

- Turn on Bluetooth (BT) on your mobile device A.
- 2. Turn on Headphones, (Headphones will enter BT pairing mode)
- Search and connect to "FB-X850BANC" from mobile device A.
- 4. Turn off BT on mobile device A, and repeat the above for mobile device B
- 5. Turn on Mobile device A again and the headphones will pair to both devices

Connecting the Product



- 1. Turn on Bluetooth (BT) on your mobile device.
 - 2. Turn on Headphones. (Headphones will enter BT pairing mode)
 - 3. Search and connect to "EB-X850BANC" from your mobile device

2nd Incoming phone call from the other device during 1st phone call EB-X850BANC will automatically connect to the last paired device if device is on and

End current call. answer 2nd phone call







Click MFB once

Call Control while connected to 2 devices.

It will automatically prioritize incoming calls/ notifications and audio playback (Pause music on one device, and play music on the other)



Click MFB once (1) to answer incoming phone call





automatically.

Reject the 2nd

incoming call

ouble Click MFB

ick MFB once (1

Charging: *Red Indicator Light* Full Charge: *Extinguished Indicator Light*

Approximate charging time: 2 Hours

Battery & Charging

EB-X850BANC will turn off automatically after 5 minutes of disconnection/inactivity. Please charge the headphones every six (6) months.

Please visit www.int-aiwa.com for more product information.

Customer Service

Contact your local authorized dealer/ customer service by referring to the warranty label/receipt provided with your purchase.



Aiwa Electronics Int'l Co., Ltd. Explore more at <u>www.int-aiwa.com</u>





