

Safety Instructions

- ① Avoid dropping.
- ② Avoid falling into the water
- ③ Do not submerge in water.
- ④ Avoid extreme temperatures.
- ⑤ Do not use the device outdoors during a thunderstorm.
- ⑥ Use original or certified cables.
- ⑦ Do not use any corrosive cleaner/oil to clean.

Hearing Safety


- ① To avoid hearing damage, do not listen for extended periods at high volume.
- ② Do not turn the volume so high that you're unable to hear your surroundings.
- ③ You should always exercise caution and do not use earbuds in a potentially hazardous situation.



Unboxing




Charging Case X1



Earbuds X 1 Pair



Silicone Ear Tips X2 Pairs



Type-C Cable X1

Product/Accessories Checklist:

1. 1X Pair of TWS Earphones
2. 1X Type-C Charging Cable
3. 2X Pairs of Silicone Ear Tips
4. 1X User Manual

Using Your Headset

Power On
1. Auto power on - Take out both earphones from the charging case.
2. Long press touch sensor (Side surface of the earphone) for approx. 1.5 seconds.

Blue Light flashing indicates power on

Power Off
1. Auto power off - Place earphones back into charging case.
2. Long press touch sensor for approx. 3 seconds.

Red light flashing indicates power off sequence

Earphones will shut down automatically after 3 minutes when disconnected.

2. Charging your earphones




Charging ● Steady red	Fully charged ● Red light off
--------------------------	----------------------------------

Use the included USB cable to charge your headset. Make sure they are fully charged before first use. To preserve battery lifespan, fully charge at least once every 4-5 days.

4. Pairing your device



1. Long press the touch sensor to enter pairing mode (Approx. 3 Seconds).
Alternating Red and Blue light flashing indicates earphones is in pairing mode
2. Turn on Bluetooth on your device.



3. Find and connect to "AT-X80J".

Flashing red and blue alternately Pairing mode

When turned on, Headset will automatically connect to the last connected device if available. If not, Headset will enter pairing mode.

5. Music

Play/Pause Short press touch sensor once	
Play/Pause Short press touch sensor once	
Next Song Double click the "R" earphone touch key when music is on	
Previous song Double click the "L" earphone touch key when music is on	
Volume + Triple click the "R" earphone touch key when music is on	
Volume - Triple click the "L" earphone touch key when music is on	

※ In order to get the best audio experience and comfort, please choose the most suitable ear tips.

An incoming call automatically pauses your music playback. Music playback resumes after the call is ended/ignored.

6. Call Control

Answer Call Short press touch sensor once	
Reject Call Long press touch sensor (approx. 2 seconds)	
End Call Short press touch sensor once	

	In a call
	Incoming call

7. Siri

Enable Siri: Long press touch sensor on either earbuds for approx. 1.5 seconds.



Specifications

Specifications are subjected to change without prior notice.

Input	5V 1A
Charging time	1.5 hours
Play time (varies by volume level and content)	about 4 hours
Earphone battery capacity	40mAh
Frequency range	2.4G-2.48GHz
Standby time	About 100 hours
Charging bin battery capacity	260 mAh
Range	10 m / 33 ft

Warning: Rechargeable batteries must be disposed properly. Please contact your local disposal/recycling center for proper disposal. Do not expose the batteries to fire.

Troubleshooting

I can't find "AT-X80J" on my Bluetooth's device's list.

Make sure "AT-X80J" and your device are within Bluetooth working distance (10m). Remove the earphones from the charging case, enter pairing mode manually. Re-attempt to pair again.

My earbuds can only answer calls/ only listen to songs.

Re-start the earbuds. (Power down then power up) Turn off mobile device's Bluetooth and turn it back on. Delete all pairing data within mobile device. Re-attempt to pair again.

There is no sound coming from my earbuds.

Please check volume level on both earbuds and connected mobile device. Make sure "AT-X80J" and your device are within Bluetooth working distance (10m). Re-attempt to pair again.

Unstable connection

Make sure "AT-X80J" and your device are within Bluetooth working distance (10m).

Maintenance

Please read the following suggestions to help you comply with the warranty and extend the life of the product.

- Keep the product dry and do not place it in a damp place, so as not to affect the internal circuit of the product. It is necessary to avoid using this product during intense exercise or sweating to prevent sweat from penetrating into the product and damaging the product.
- Do not place the product in a place exposed to the sun or high temperatures. High temperatures can shorten the life of electronic components, damage batteries, and deform some plastic parts.
- Do not place the product in a cold place to avoid damaging the internal circuit board.
- Do not attempt to disassemble the product. If you are not a professional, you may damage the product.
- Do not drop, strongly vibrate, or hit the product with hardware to avoid damaging internal circuits.
- Do not use harsh chemicals or detergents to clean the headphones.
- Do not use sharp objects on the surface of the product to avoid damage to the outer casing and affect the appearance.

If the product does not work properly, please send it to your qualified service facility and the staff will be happy to help you solve the problem.

WARRANTY

This product is covered under warranty for a period of one year from the date of sale limited to normal use and maintenance of the machine parts, materials and functions. Problems and failures verified upon further identification will be provided free repair and replacement parts.

This warranty does not apply:

- (a) to a product that is out of warranty;
- (b) to damage caused by operating the product outside the permitted or intended usage described.
- (c) to a product that has been disassembled, repaired or refitted by any third parties.
- (d) if warranty card and proof of purchase cannot be presented;
- (e) to damage caused by earthquake, fire or other external causes, natural disasters, etc.

Note: The warranty does not include product transport costs and does not provide on-site maintenance services

AIWA reserves all rights to clarify this warranty interpretation

WARRANTY FEEDBACK FORM (TICK OFF)

- | | |
|------------------------------|------------------------------|
| A. No sound | D. Faulty Pairing |
| B. Faulty sound | E. Recharging problem |
| C. Button malfunction | F. Others |

Buying time _____

Dealers of sale _____

Time of problems _____

User's contact info _____